



CLEAR VIEW WINDOW FILM

100CM X 76CM (AFWF)

FITTING INSTRUCTIONS

1. Before attempting to fit the film ensure the glass you're applying it to is free from any dirt or silicone/solvent based cleaner.
2. Cut to the desired size you wish to use.
3. The film itself has a removable ultra-thin film on both sides. To separate easily, apply a small piece of Sellotape to each side edge corner and you'll be able to pull it apart. The lightly adhesive backed side adheres directly to the glass you're applying it to and needs to be removed first.
4. Before applying directly to the glass, cover both the lightly adhesive side and glass with a light soapy water to avoid the film sticking directly to the glass. This allows for some final movement when positioning.
5. Once in your desired position and using a squeegee, push all the air bubbles and excess fluid from between the film and glass. The film will not be fully bonded to the glass until fully dry, which can take 2-3 hours depending on the ambient temperature.
6. You then need to remove the inner ultra-thin film which leaves you with a Clear view hydrophobic surface.
7. DO NOT wash or clean this inside surface for 4-6 weeks. This will be hugely detrimental to the effectiveness of the hydrophobic properties and needs to be avoided at all costs.

Enjoy your new clear view glass in all conditions.