

R35 Coil Bracket for Toyota JZ

- Includes mounting hardware and PCV block off



Instructions

- 1.) Disconnect the battery negative cable from the battery to avoid any chances of an electrical short.
- 2.) Remove the ignition coil cover, existing ignition coils, ignition leads and ignition harness. Depending on the engine, the valve cover balance breather ports may need to be removed, blocked off with the supplied plugs, and only the outer ports used for coil clearance.
- 3.) Install the R35 ignition coil bracket and ignition coils onto the cylinder head using the included mounting hardware.
- 4.) Before powering up the R35 ignition coils, ensure that the Haltech ECU is set to use direct fire, falling edge, constant charge dwell mode, and the recommended R35 ignition coil dwell times for the ignition system settings. Failure to do so will damage the ignition coils resulting to no spark or low spark energy.
- 5.) Plug the Haltech ignition coil harness, reconnect the battery, and proceed to start the engine.

HT-120100		
Revision #1		